

## Private Automatic Branch Exchange PABX 1

A PABX offers automatic internal telephone service and public exchange service in a single system.

Each automatic extension can dial other extensions and make or receive exchange calls.

The PABX 1 meets the telephone requirements of small and medium size organisations needing up to 10 exchange lines and 49 automatic extensions.



## Description

The installation is available in four separate sizes. The largest can accommodate up to 10 exchange lines and 49 automatic extensions.

A few manual extensions and/or lines to other Private Branch Exchanges (PBXs) can be provided but these reduce the number of automatic extensions and in some cases the number of exchange lines (see size chart opposite). The distant PBX may be either automatically (PABX) or manually (PMBX) operated.

The PABX operator receives incoming exchange calls on the compact switchboard, illustrated below, and assists the extensions as necessary.

The automatic equipment is contained in a metal cabinet which is usually sited in a small room near the switchboard.

The equipment is powered from a secondary-cell battery, automatically charged from a mains unit.

## General facilities

Automatic extensions call each other and manual extensions by dialling two-digit numbers between 21 and 69, the range depending on the PABX size.

Automatic extensions dial 9 to get an exchange line to make outside calls. If required, selected extensions can be denied direct access to the public exchange; such calls being set up via the switchboard.

Timing of any outgoing exchange call stops and the exchange line is released as soon as the extension handset is replaced.

Incoming exchange calls are received on the switchboard, and connected by the operator to the required extensions.

Automatic extensions dial 7 to get a line connected to another PBX. It may be possible to dial direct to an extension of another PABX over these lines.

Two other PBX or private circuits, to different destinations if required, can be connected in place of two automatic extensions. They are obtained by dialling the appropriate extension numbers.

Automatic extensions dial 0 to call the PABX operator.

Manual extensions make all outgoing calls through the switchboard, but receive calls automatically.

Calls are not interrupted if there is a mains failure. Service on the PABX can be maintained for several hours by the battery, subject to the load.

## Switchboard facilities

The operator calls extensions from the switchboard by pushing buttons in sequence for the required number. Ringing is normally applied automatically to extensions.

Calls to or from extensions are released when the extension handset is replaced.

If an extension is engaged, the PABX operator can let an exchange line caller hold on, to be connected automatically to the extension as soon as it becomes free.

The PABX operator can interrupt an engaged extension to ask if another call can be accepted. A ticking sound (warn tone) lets the extension know that the operator is on the line.

An exchange call can be held by the operator who connects it to a special 'hold' number. The call can then be connected to an extension when required. More than one call may be held in this way, without overhearing.

## PABX 1 Sizes

Size	4 + 15	5 + 24	7 + 35	10 + 49
The capacity shown for each unit cannot be exceeded. Greater capacity can be obtained only by changing the unit for a larger size.				
<b>Exchange lines</b> If 3 inter-PBX lines are required, exchange lines on 10 + 49 are limited to 9.	4	5	7	10
<b>Automatic extensions</b> Reduced by one for each manual extension or inter-PBX line that is provided.	15	24	35	49
<b>Manual extensions</b>	2	2	4	4
<b>Inter-PBX lines</b>	2	2	3	3
<b>Connecting circuits</b>	3	4	6	7
<b>Enquiry transfer circuits</b>	1	1	1	1
<b>Operator assistance circuits</b>	2	2	2	2

## Extension facilities

Calls between extensions are released when either extension handset is replaced.

On exchange calls, or calls to another PBX, the button on the telephone is pressed twice to call in the PABX operator, who can then hold or transfer the call as required.

An automatic extension can hold an exchange call and make an enquiry of another extension by pressing the button once and dialling its number. Pressing the button again, restores the original extension to the exchange call. Alternatively, if the handset on the original extension is replaced, the call is transferred to the other extension.

Exchange or inter-PBX calls can be transferred as often as required. If the enquiry circuit is engaged the operator will be called in automatically.

## Night service facilities

When the night service button on the switchboard is pressed, incoming exchange calls cause suitably sited bells to ring continuously.

Any automatic extension dials 8 to answer the call, which can then be transferred to any other extension.


Another method can be provided, at additional rental, which enables individual exchange lines to be connected to selected extensions.

## Conference facilities

A separate unit can be rented which allows up to eight extensions (internal or external), or private circuits to be connected together for a telephone conference. Alternatively up to five extensions and one exchange line, may be similarly connected.

An amplifier can also be rented, to allow up to seven extensions and an exchange line to have a conference.

Distribution frame and cabinet for a 4 + 15 PABX 1 installation.



## General Information

### Dialling codes usually provided

<b>7</b>	To get lines to another PBX.
<b>8</b>	For answering calls on night service.
<b>9</b>	To get exchange lines.
<b>0</b>	To call the PABX operator.
<b>20</b>	Used by PABX operator for holding calls.
<b>21 to 35</b>	For 15 extensions.
<b>21 to 44</b>	For 24 extensions.
<b>21 to 55</b>	For 35 extensions.
<b>21 to 69</b>	For 49 extensions.

**Alarms** Audible and visual signals on the switchboard draw attention to incoming calls, mains failure and fault conditions.

The audible alarm can be switched off when required. It is also switched off when the night service facilities are in use.

**Tones** Dialling, ringing, engaged, 'warn' and number unobtainable tones are provided from the PABX equipment.

**Accommodation** The automatic equipment cabinet, battery, mains unit and distribution frame should ideally be installed in a separate room as near as possible to the switchboard. The room should have adequate heating, lighting and ventilation.

Sufficient space has to be left around the equipment for maintenance purposes. The cabinet has doors front and rear, so that the engineer can get at both sides of the equipment racks.

An exclusive mains 3-pin socket of at least 5 amp rating in the equipment room must be provided by the customer.

The room should be at least 2300mm high, with not less than the following dimensions.

**4 + 15 or 5 + 24 size** –  
2600mm by 2050mm


**7 + 35 or 10 + 49 size** –  
2700mm by 2400mm

## Dimension and weights of equipment

Equipment	Width	Depth	Height	Weight
<b>Cordless manual switchboard</b>	495mm	330mm	203mm	11 kg
<b>4 + 15 or 5 + 24 cabinet</b>	864mm	610mm	2108mm	419-445 kg
<b>7 + 35 or 10 + 49 cabinet</b>	1111mm	610mm	1816mm	550-584 kg
<b>Distribution frame</b>	457mm	610mm	2057mm	73 kg
<b>Mains rectifier unit</b>	394mm	241mm	527mm	24 kg
<b>Secondary- 4+15, 5+24 or cell</b>	991mm	229mm	1689mm	96 kg
<b>battery</b>	10+49 size	1321mm	229mm	168 kg

The table above quotes approximate dimensions and weights. Equipment modification and development may result in the dimensions and weights of an installation varying from those shown above.

## Typical layout of equipment room



### Note:

The floor plan shown is for a basic installation. Additional facilities may require extra accommodation. Customers are advised to discuss equipment room requirements with the P.O. before planning PABX accommodation.

### Please note

We do our best to supply our customers with the apparatus they ask for but we may have to provide apparatus which does not accord exactly with the descriptions and illustrations in this leaflet.

**Your Telephone Sales Office will gladly supply any further information or details of any changes in the information in this leaflet since it went to print. The address and telephone number are shown in the preface of your telephone directory. Information on a wide range of our services and apparatus is contained in the Green Pages section of most Telephone Directories.**